



Port-A-Strop
1453 Carol St.
Camano Island, WA 98282
(360)-387-6701
(425)-320-8999

Email: info@portastrop.com

www.portastrop.com

Port-A-Strop Manual

Port-A-Strop is a light-weight, battery-powered honing, and sharpening system, that was designed for portability. This portable light weight machine is great for stropping or honing most tools. With the addition of sandpaper to the rotating wheel, it also works great to sharpen small tools. Below you will find all the information you need to order new parts, proper use of the Port-A-Strop, and warranty information. Please read the entire content of this manual and if you have any questions, please contact Port-A-Strop at the numbers list above.

Port-A-Strop Specs

Portable, Cordless, Stropping Machine With Battery Charger
Port-A-Strop RPM 500
Battery 14.4 VDC battery provided, 1.3 amp-hour
Charger 120 VAC (input) charger, 3-5 hours UL approved

Contact Port-A-Strop

Replacement parts, service, returns, and product information. Please contact Port-A-Strop directly.

Port-A-Strop
(360)-387-6701
(425)-320-8999

Email: info@portastrop.com

One Year Limited Warranty

Port-A-Strop makes every effort to assure that this product meets high quality and durability standards and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 1 year from the date of purchase. This warranty does not apply to damage due directly or indirectly to misuse, abuse, negligence or accidental, repairs or alterations outside our facilities, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special or consequential damages arising from the use of our product.

To take advantage of this warranty, the product or part must be returned to us with shipping charges prepaid. Proof of purchase date, the receipt, and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election. We will return the repaired product at our expense but if we determine there is no defect or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product. Tampering in any way with this box will make the warranty null and void.

The battery and charger are warranted for 90 days.

PORT-A-STROP SAFETY

Below you will find safety and operation instructions for your Port-A-Strop. To obtain satisfaction from your Port-A-Strop. The manufacturers suggest you follow the guidelines below.

WARNING: When using tools, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

ALWAYS: Wear safety glass while operating the Port-A-Strop.

READ ALL INSTRUCTIONS BEFORE USING THIS TOOL

1. **Keep work area clean.** Cluttered areas invite injuries
2. **Observe work area conditions.** Do not use machine in damp or wet location. Don't expose to the rain. Keep work area well lighted. Do not use in the presence of flammable gases or liquids.
3. **Keep Children away.** Children must never be allowed in the work area. Do not let them handles this machine or extension cords.
4. **Store equipment.** Always keep this machine out of the reach of children.
5. **Do not force tool.** It will do the job better and more safely at the rate for which it was intended. Do not use inappropriate attachments in an attempt to exceed the tool capacity.
6. **Dress properly.** Do not wear loose clothing_or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes. Wear restrictive hair covering to contain long hair.
7. **Use eye and ear protection.** Always wear ANSI approved impact safety goggles and ear protection. Wear an ANSI approved dust mask or respirator when working around metal, wood, and chemical dusts and mists.
8. **Do not overreach.** Keep proper footing and balance at all times. Do not reach over or across running machines.
9. **Maintain tool with care.** Care of leather use a rouge or polishing compound of your choice. Follow instructions for changing accessories. Inspect tool cord periodically and if damaged, have them repaired by an authorized technician.
10. **Disconnect power.** Unplug charger when not in use.
11. **Avoid unintentional starting.** Be sure the switch is in the OFF position when not in use. Do not carry the tool with your finger on the switch.
12. **When using Strop.** Place one hand firmly on top of the box and hold tool firmly in place while stropping.
13. **Stay alert.** Watch what you are doing. Use common sense. Do not operate any tool when you are tired.
14. **Check for damaged parts.** Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment and binding of moving parts; any broken parts or mounting fixtures; and any other condition that may affect proper operation. Any part that is damaged should be repaired or replaced by a qualified technician. Do not use the tool if any switch does not turn On and Off properly.
15. **Replacement parts and accessories.** When servicing use only identical replacement parts. Use of any other parts will void the warranty. Only use accessories intended for use with this tool.
16. **Do not operate tool if under the influence of alcohol or drugs.** Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the tool.
17. **CAUTION!!!**
Do not charge the Battery for more than 5 hours
DO NOT USE THE MACHINE WHILE THE PORT-A-STROP IS CHARGING!!!

Warning: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors, which cannot be built into this product, but must be supplies by the operator.

